

SPACEKAP

Current Truck / Camion Courant									
	1999-2006 GMC/Chevrolet	2007+ GMC/Chevrolet	2002-2008 Dodge Ram	2009+ Dodge Ram	2004-2008 F-150	2009+ F-150	F-250/350/450 1999+	Toyota Tundra 2007+	
New Truck / Nouveau Camion	1999-2006 GMC/Chevrolet	N/A	MP3 PAT009 (1) KIT GL99-06BO	KIT GL99-06BO	KIT GL99-06BO	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT GL99-06BO	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT GL99-06BO	KIT GL99-06BO	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT GL99-06BO
	2007+ GMC/Chevrolet	MP7 PAT120 (1) KIT GL07-BOIS	N/A	MP7 PAT120 (1) KIT GL07-BOIS	MP7 PAT120 (1) KIT GL07-BOIS	MP3 PAT008 (1) MP3 PAT120 (1) MP3 PAT011 (2) MP3 MON010 (2) KIT GL07-BOIS	MP3 PAT008 (1) MP3 PAT120 (1) MP3 PAT011 (2) MP3 MON010 (2) KIT GL07-BOIS	MP7 PAT120 (1) KIT GL07-BOIS	MP3 PAT008 (1) MP3 PAT120 (1) MP3 PAT011 (2) MP3 MON010 (2) KIT GL07-BOIS
	2002-2008 Dodge Ram	KIT DS09+BOIS	MP3 PAT009 (1) KIT DS09+BOIS	N/A	N/A	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT DS09+BOIS	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT DS09+BOIS	KIT DS09+BOIS	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT DS09+BOIS
	2009+ Dodge Ram	KIT DS09+BOIS	MP3 PAT009 (1) KIT DS09+BOIS	N/A	N/A	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT DS09+BOIS	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT DS09+BOIS	KIT DS09+BOIS	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT DS09+BOIS
	2004-2008 F-150	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	N/A	N/A	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) KIT 15004+BOI
	2009+ F-150	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	N/A	N/A	MP7 PAT100 (4) MP7 MON100 (4) KIT 15004+BOI	MP7 PAT100 (4) KIT 15004+BOI
	1999+ F-250/350/450	KIT FLHD99BOI	MP3 PAT009 (1) KIT FLHD99BOI	KIT FLHD99BOI	KIT FLHD99BOI	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT FLHD99BOI	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT FLHD99BOI	N/A	MP3 PAT008 (1) MP3 PAT009 (1) MP3 PAT011 (4) MP3 MON010 (4) KIT FLHD99BOI
	Toyota Tundra 2007+	MP7 PAT020 (4) MP7 MON100 (4) KIT TUND07BOI	MP7 PAT020 (4) MP7 MON100 (4) KIT TUND07BOI	MP7 PAT020 (4) MP7 MON100 (4) KIT TUND07BOI	MP7 PAT020 (4) MP7 MON100 (4) KIT TUND07BOI	MP7 PAT020 (4) KIT TUND07BOI	MP7 PAT020 (4) KIT TUND07BOI	MP7 PAT020 (4) MP7 MON100 (4) KIT TUND07BOI	N/A